



Application Guidelines Concrete Roof

1.0 GENERAL

This specification is provided as a general guide for use of Liquid Rubber products based on typical building conditions and standard roofing practices. Liquid Rubber recommends that the Owner's representative independently verify the accuracy and appropriateness of a specification provided for a specific project. Additionally, the roof and any underlying insulation should be analyzed for water saturation.

2.0 INSPECTION

Improperly prepared surfaces can result in the reduction of the service life and performance of the membrane coating. A thorough inspection of the roof prior to beginning work should be performed to ensure adhesion and the integrity of the coating. At a minimum, the following must be confirmed:

2.1 A satisfactory surface for application and the soundness of the existing roof deck.

2.3 Surface must be free of voids and irregularities. 1/8th inch voids or less must be filled with Liquid Rubber B-400 and larger voids sealed with Liquid Rubber HighBuild S-100/200 and geotextile fabric.

2.4 The drainage of the roof's surface must be functioning properly.

2.5 A moisture meter or core samples must be used to determine the presence of water saturation as a result of existing leaks.

2.6 If an existing coating is present, determine the soundness and the compatibility of the coating to Liquid Rubber SealRoof products by coating a small test area.

3.0 GENERAL PREPARATION AND CLEANING

Liquid Rubber SealRoof products must be installed on a clean, dry and structurally sound surface that is free of sharp edges, dirt, debris, oil, grease, coal tar, mastics, flaking paint, silicone, other coatings or other contaminants.

3.1 All loose concrete, laitance, sharp edges, oil or unusual stains must be removed. Power washing is recommended to provide a clean bonding surface.

3.2 If the surface needs to be washed, allow the deck to dry until it is free of surface and retained moisture.

3.3 Surface must be free of voids and irregularities. 1/8th inch voids or less must be filled with Liquid Rubber B-400 and larger voids sealed with Liquid Rubber HighBuild S-100/200 and geotextile fabric.

3.4 Clean and remove any loose rust or scale from metal surfaces.

3.5 Prepare pipes by sanding Metal / PVC / ABS pipes to a min. 4"/10 cm at juncture of pipe penetration. Clean PVC / ABS with acetone, rinse with clean water and dry.

3.6 Install protective covers over drain grates.

3.7 Mask areas as needed for protection against over spray.

3.8 Allow detail work to cure for 12 hours prior to applying Liquid Rubber SealRoof spray products overtop.

Using the 3 Course Method

The **3-course method** for sealing cracks and penetrations uses Liquid Rubber HighBuild S-100/200 and various widths of Liquid Rubber reinforcing geo-textile fabrics. Use heavy coats for all steps.

A. Measure and cut a length of Liquid Rubber geo-textile fabric and ensure the fabric overlaps 6"/15 cm on all sides of the area in question. Apply a coating to one side using HighBuild S-100/200.

B. Apply a coat of HighBuild S-100/200 over the surface extending 6"/15cm on both sides and imbed the coated side of the geo-textile into the coated surface.

C. Allow it to tack up and apply a coat of HighBuild S-100/200 over the geo-textile. Allow it to dry for approx. 3-4 hours and apply a 2nd coating.

D. Close fish mouths (openings) by pushing them down and back brushing HighBuild S-100/200 into the openings.

4.0 SEALING THE ROOF EDGE/PERIMETER-GENERAL

The preparation and application specification pertains to various types of the roof's edge perimeter including cap flashing, coping, parapet walls and gravel stops. For walls with metal cap flashing or coping covers, the recommended procedure is to remove the cover, repair any damage to the coping or parapet wall, apply 3-course method and replace the cap flashing.

4.1 Fill non-structural voids and cracks in the coping and wall with HighBuild S-100/200 and/or TrowelGrade B-400 then employ the 3-course method for cracks over 0.25"/0.6mm.

4.2 Where base flashing has not been installed or where there are 90° turn-ups at the intersection of the roof to wall, apply a 0.75" x 0.75"/2cm x 2cm fillet using HighBuild S-200 and/or TrowelGrade B-400.

4.3 Starting from the horizontal top of the wall or coping apply 3-course method using Liquid Rubber 12"/30cm wide geo-textile reinforcing fabric terminating down and across 6"/15cm onto the flat of the roof surface.

4.4 When the roof's edge has only a gravel stop apply the 3-course method using Liquid Rubber geo-textile fabric terminating to the outer edge of the gravel stop.

5.0 SEALING PIPE PENETRATIONS, SCUPPERS, VENTS, PITCH PANS, CURBS AND SKYLIGHTS

5.1 Clean and remove any loose rust scale, excess caulking or mastic.

5.2 PIPE PENETRATIONS: General recommendation is to replace old pipe flashings with retrofit wrap around pipe flashing boots or install pitch pans with precast components and pourable sealants. Seal with HighBuild S-200 over the boot and down across the roof surface several inches.

Alternative method to seal pipe penetrations is to measure and cut a length of Liquid Rubber geo-textile fabric 3"/ 7.5 cm longer than the circumference of the pipe. Cut 3"/7.5cm long slits every 1"/2.54 cm apart along one edge. Apply a coat of HighBuild S-200 extending 4"/10 cm on the pipe from the juncture of the pipe penetration and down across the flange and terminating 4"/10 cm across the flat of the roof. Use 3-course method and wrap the fabric around the pipe with the slits splayed out across the roof surface.

5.3 DRAINS: Inspect drain seals, replace if damaged. Apply a coat of HighBuild S-200 over the gravel guard and out 6"/15 cm across the roof surface.

5.4 SCUPPERS: Inspect and replace the scuppers if they are in poor condition. Use the 3-course method over the scupper flange if exposed and not sealed to the roof surface using geo-textile. Apply a coat of HighBuild S-100/200 to the inside of the conductor head and around where the downspout meets.

5.5 SKYLIGHTS, VENTS AND ROOF CURBS: Seal around units using the 3-course method using geo-textile.

6.0 APPLICATION OF BASE COAT AND TOP COAT - GENERAL

The recommended DFT (dry film thickness) for Liquid Rubber SealRoof products is 80-mil/2.0 mm DFT.

Base coat: Final DFT for SealRoof B-200 will be 60-mil/1.5 mm.

Top Coat: Apply SealRoof A-200 @ 20 mil/ 0.5 mm. DFT.

Note: If topcoat of SealRoof A-200 is not applied, increase SealRoof B-200@ DFT to 80 mil/2.0 mm.

6.1 Begin by spraying Part A only, **meaning the SealRoof B-200 without the calcium chloride**, over the entire concrete surface at the rate of 10 wet mils to prime the surface. This will also fill any voids that were missed during the prep work. Allow drying to the touch before building the membrane.

6.2 Follow by applying Liquid Rubber SealRoof B-200 part A & B (instant set) @ 80-100 wet mils to all vertical/horizontal intersections such as wall/roof turn-ups, fillets. Apply in a crosshatch pattern with 2-3 passes in each direction with a 50% overlap. This will result in a 50-70 mil DFT or 1.5 mm.

6.3 Details where the 3-course method was applied should receive 20 wet mils. This should extend 4"/10 cm up the vertical surface and across the horizontal surface and at the corners.

6.4 Top Coat: Before applying the topcoat, wash the instant set salt residue off and allow to completely dry. Apply Liquid Rubber SealRoof A-200 @ 30 wet mils to yield 20 mil/ 0.5 mm DFT. Apply 2 coats SealRoof A-200, allowing approximately 3 hours curing time between coats.

6.5 Test the Liquid Rubber SealRoof System to ensure that it is sufficiently cured by using a moisture gauge. The moisture content must be lower than 10%. If traffic is anticipated, apply a liquid Rubber T-300 over installed membrane for protection.

7.0 Product Curing Precautions

7.1 Curing time depends on weather conditions. A minimum of 24-36 hours curing time is normally required at 70F/20C and 50% humidity for a 80 mil/2 mm DFT membrane to fully cure. Curing times can be enhanced with air movement (fans) and heaters. If rain is expected within 24 hours, delay installation.

7.2 Conditions such as cold temperature, high humidity or airflow may delay full adhesion and curing of the membrane subject to the membrane thickness and severity of conditions.

8.0 Post Installation Inspection

8.1 Upon completion, inspect the entire roof surface for uniformity of membrane thickness in grid patterns of 150 FT²/45 M².

For more information, please consult a Liquid Rubber technical representative @ 855-592-1049, 8:30 AM – 5:00 PM EST.

The information contained herein is the best available to Liquid Rubber Worldwide Inc and its affiliated companies relating to our products and the use of our products. It is based on tests believed to be reliable. There is no warranty expressed or implied in association with the products use. Liquid Rubber Worldwide Inc. assumes no liability for any damages incurred in association with the use of Liquid Rubber Worldwide Inc. products. Information is subject to change without notice.

APPLICATION GUIDELINE REV. 08/12